

## RFL500 RFID Locker / Cabinet Lock

This lock must be installed on the inside of the door or cabinet. The door or cabinet must be non-metallic, such as wood, plastic, or fiberglass and no more than 1" thick to allow for communication between the lock and the user RFID card. The user access RFID card is simply held on the outside of the locker or cabinet over the area where the RFL500 is located, and the latch is retracted or extended via an internal motor in the unit. The RFL500 is not particularly sensitive to up, down, or sideways mounting orientation. The reset button is used during initial setup to program access cards or to completely clear user data from the lock. No computer is required to program the lock for user cards.

